

# ST-EZ16

# QUICK START GUIDE



# TABLE OF CONTENTS

<b>NVR Installation .....</b>	<b>6</b>
<b>Hard Disk Installation .....</b>	<b>6</b>
<b>Front Panel .....</b>	<b>8</b>
<b>Rear Panel .....</b>	<b>9</b>
<b>Specifications .....</b>	<b>10</b>
Specifications .....	10
Specifications .....	11
<b>HDD Storage Calculation Chart .....</b>	<b>12</b>
<b>Menu Operation .....</b>	<b>13</b>
Menu Structure .....	13
Startup and Shutdown .....	13
Setting the Admin Password .....	14
Login and Logout .....	15
User Login .....	15
User Logout .....	15
Live View .....	16
Adding IP Cameras .....	16
Recording .....	19
Instant Recording .....	19
All-day Recording .....	19
Playback .....	19
Backup .....	21
VCA Detection .....	22
VCA Search .....	22
<b>Accessing by Web Browser .....</b>	<b>24</b>
Logging In .....	24
Live View .....	25
Recording .....	26
Playback .....	28
<b>Mobile Device Access .....</b>	<b>29</b>

## **Quick Start Guide**

### **About this Manual**

This Manual is applicable to Securitytronix EZII Network Video Recorders (NVR).

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons.

Please use this user manual under the guidance of professionals to ensure a safe and proper deployment.

### **Legal Disclaimer**

THIS HARDWARE AND SOFTWARE IS PROVIDED BY SECURITYTRONIX "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL SECURITYTRONIX S BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS HARDWARE AND SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

THE USE OF THE PRODUCT SHALL BE WHOLLY AT YOUR OWN RISK. SECURITYTRONIX SHALL NOT BE LIABLE FOR ANY ABNORMAL OPERATION, BREACH OF PRIVACY OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS. SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT USE CONFORMS TO ALL APPLICABLE LAWS. SECURITYTRONIX SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

**For further assistance, or if you encounter any issue while using this product, please contact your distributor or Securitytronix at: 800-688-9282 Press 3 for support, then 2 for CCTV.**

## Regulatory Information

### FCC Information

**FCC compliance:** This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

### EU Conformity Statement



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2004/108/EC, the RoHS Directive 2011/65/EU.



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: [www.recyclethis.info](http://www.recyclethis.info)



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: [www.recyclethis.info](http://www.recyclethis.info)

### Industry Canada ICES-003 Compliance

This device meets the CAN ICES-3 (B)/NMB-3(B) standards requirements.



## Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

The precaution measure is divided into “Warnings” and “Cautions”

**Warnings:** Serious injury or death may occur if any of the warnings are neglected.

**Cautions:** Injury or equipment damage may occur if any of the cautions are neglected.

	
<b>Warnings</b> Follow these safeguards to prevent serious injury or death.	<b>Cautions</b> Follow these precautions to prevent potential injury or material damage.



### Warnings

- Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.
- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. Please refer to technical specifications for detailed information.
- Input voltage should meet both the SELV (Safety Extra Low Voltage) and the Limited Power Source with 100~240 VAC or 12 VDC according to the IEC60950-1 standard. Please refer to technical specifications for detailed information.
- Do not connect several devices to one power adapter as adapter overload may cause over-heating or a fire hazard.
- Please make sure that the plug is firmly connected to the power socket.

If smoke, odor or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

## Preventive and Cautionary Tips

Before connecting and operating your device, please be advised of the following tips:

- Ensure unit is installed in a well-ventilated, dust-free environment.
- Unit is designed for indoor use only.
- Keep all liquids away from the device.
- Ensure environmental conditions meet factory specifications.
- Ensure unit is properly secured to a rack or shelf. Major shocks or jolts to the unit as a result of dropping it may cause damage to the sensitive electronics within the unit.
- Use the device in conjunction with an UPS if possible.
- Power down the unit before connecting and disconnecting accessories and peripherals.
- Surveillance grade HDDs should be used for this device.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.

Thank you for purchasing our product. If there is any question or request, please do not hesitate to contact dealer.

## NVR Installation

During the installation of the NVR:

1. Use brackets for rack mounting.
2. Ensure there is ample room for audio and video cables.
3. When routing cables, ensure that the bend radius of the cables are no less than five times than its diameter.
4. Connect both the alarm and RS-485 cable.
5. Allow at least 2cm ( $\approx 0.75$ -inch) of space between racks mounted devices.
6. Ensure the NVR is grounded.
7. Environmental temperature should be within the range of , 14°F ~ 131°F.
8. Environmental humidity should be within the range of 10% ~ 90%.

## Hard Disk Installation

### *Before you start:*

Disconnect the power from the NVR before installing a hard disk drive (HDD). Surveillance grade HDDs should be used for this installation.

Up to 2 SATA hard disks can be installed on your NVR.


**Tools Required:** Screwdriver.

### *Steps:*

1. Remove the cover from the NVR by unfastening the screws on the rear and side panel.



2. Connect one end of the data cable to the motherboard of NVR and the other end to the HDD.



3. Connect the power cable to the HDD.




4. Place the HDD on the bottom of the device and then fasten the screws on the bottom to fix the HDD.



5. Re-install the cover of the NVR and fasten screws.

## Front Panel




No.	Name	Function Description
1	<b>POWER</b>	POWER indicator turns green when NVR is powered up.
	<b>STATUS</b>	STATUS indicator lights in red when data is being read from or written to HDD.
	<b>Tx/Rx</b>	Tx/Rx indicator blinks green when network connection is functioning properly.
2	<b>DIRECTION</b>	<p>The DIRECTION buttons are used to navigate between different fields and items in menus.</p> <p>In the Playback mode, the Up and Down button is used to speed up and slow down recorded video. The Left and Right button will select the next and previous record files.</p> <p>In Live View mode, these buttons can be used to cycle through channels.</p> <p>In PTZ control mode, it can control the movement of the PTZ camera.</p>
	<b>ENTER</b>	<p>The ENTER button is used to confirm selection in any of the menu modes. It can also be used to <i>tick</i> checkbox fields.</p> <p>In Playback mode, it can be used to play or pause the video.</p> <p>In single-frame Playback mode, pressing the button will advance the video by a single frame.</p>
3	<b>MENU</b>	Access the main menu interface.
4	<b>ESC</b>	Exit and back to the previous menu.
5	<b>IR Receiver</b>	Receiver for IR remote.
6	<b>USB Interface</b>	Connects USB mouse or USB flash memory devices.


## Rear Panel



The rear panel vaieres according to different models.



4ch



8ch

No.	Item	Description
1	Power Supply	48V DC power supply for 4ch model and AC 100~240V for 8ch and 16ch models.
2	Audio In	RCA connector for audio input.
3	HDMI Interface	HDMI video output connector.
4	LAN Network Interface	1 10 /100 /1000 Mbps self-adaptive Ethernet interface
5	Audio Out	RCA connector for audio output.
6	VGA Interface	DB9 connector for VGA output. Display local video output and menu.
7	USB Interface	Universal Serial Bus (USB) ports for additional devices such as USB mouse and USB Hard Disk Drive (HDD).
8	Ground	Ground (needs to be connected when the NVR starts up).
9	Power Switch	Switch for turning on/off the device.
10	Network Interfaces with PoE function	Network interfaces for the cameras and to provide power over Ethernet.

# Specifications

## Specifications

Model		ST-EZ4	ST-EZ8
Video/Audio input	IP video input	4-ch	8-ch
	Two-way audio input	1-ch, RCA (2.0 V <sub>p-p</sub> , 1k $\Omega$ )	
Network	Incoming bandwidth	40Mbps	80Mbps
	Outgoing bandwidth	80Mbps	
	Remote connection	32	128
Video/Audio output	Recording resolution	6MP/5MP/3MP/1080P/UXGA/720P/VGA/4CIF/DCIF/2CIF/CIF/QCIF	
	Frame rate	Main stream: 50 fps (P) / 60 fps (N)	
		Sub-stream: 50 fps (P) / 60 fps (N)	
	HDMI/VGA output	1-ch, resolution: 1920 × 1080 /60Hz, 1600 × 1200 /60Hz, 1280 × 1024 /60Hz, 1280 × 720 /60Hz, 1024 × 768 /60Hz	
Audio output	1-ch, RCA (Linear, 1k $\Omega$ )		
Decoding	Live view / Playback resolution	6MP/5MP/3MP/1080P/UXGA/720P/VGA/4CIF/DCIF/2CIF/CIF/QCIF	
	Capability	4-ch@1080P	8-ch@720P, 6-ch@1080P
Hard disk	SATA	1 SATA interface for 1 HDD	2 SATA interfaces for 2 HDDs
	Capacity	Up to 6TB for each disk	
External interface	Network interface	1 RJ-45 10 /1000 Mbps self-adaptive Ethernet interface	
	USB interface	1 × USB 2.0 and 1 × USB 3.0	
PoE	Interface	4 independent 100 Mbps PoE network interfaces	8 independent 100 Mbps PoE network interfaces
	Max. Power	50W	120W
	Supported standard	AF and AT	
Others	Power supply	48V DC	100~240V AC
	Consumption (without hard disk and PoE)	≤10W	
	Working temperature	-10 °C ~ +55 °C (+14 °F~ + 131 °F)	
	Working humidity	10 % ~ 90 %	
	Chassis	1U chassis	19-inch rack-mounted 1U chassis
	Dimensions (W × D × H)	315 × 230 × 45mm (12.4"×9.1"×1.8")	445 × 290 × 45mm (17.5" × 11.4" × 1.8")
	Weight (without hard disk)	≤ 1 kg (2.2 lb)	

## Specifications

Model		ST-EZ16/8	ST-EZ16
Video/Audio input	IP video input	16-ch	16-ch
	Two-way audio input	1-ch, RCA (2.0 Vp-p, 1kΩ)	
Network	Incoming bandwidth	160Mbps	
	Outgoing bandwidth	80Mbps	
	Remote connection	128	
Video/Audio output	Recording resolution	6MP/5MP/3MP/1080P/UXGA/720P/VGA/4CIF/DCIF/2CIF/CIF/QCIF	
	Frame rate	Main stream: 50 fps (P) / 60 fps (N)	
		Sub-stream: 50 fps (P) / 60 fps (N)	
	HDMI/VGA output	1-ch, resolution: 1920 × 1080 /60Hz, 1600 × 1200 /60Hz, 1280 × 1024 /60Hz, 1280 × 720 /60Hz, 1024 × 768 /60Hz	
Audio output	1-ch, RCA (Linear, 1kΩ)		
Decoding	Live view / Playback resolution	6MP/5MP/3MP/1080P/UXGA/720P/VGA/4CIF/DCIF/2CIF/CIF/QCIF	
	Capability	16-ch@4CIF, 12-ch@720P, 6-ch@1080P	
Hard disk	SATA	2 SATA interfaces for 2 HDDs	
	Capacity	Up to 6TB for each disk	
External interface	Network interface	1 RJ-45 10 /100 /1000 Mbps self-adaptive Ethernet interface	
	USB interface	1 × USB 2.0 and 1 × USB 3.0	
PoE	Interface	8 independent 100 Mbps PoE network interfaces	16 independent 100 Mbps PoE network interfaces
	Max. Power	120W	200W
	Supported standard	AF and AT	
Others	Power supply	100~240V AC	
	Consumption (without hard disk and PoE)	≤10W	≤15W
	Working temperature	-10 °C ~ +55 °C (+14 °F~ + 131 °F)	
	Working humidity	10 % ~ 90 %	
	Chassis	19-inch rack-mounted 1U chassis	380 chassis
	Dimensions (W × D × H)	445 × 290 × 45mm (17.5" × 11.4" × 1.8")	380 × 290 × 48mm (15.0" × 11.4" × 1.9")
	Weight (without hard disk)	≤ 1 kg (2.2 lb)	

## HDD Storage Calculation Chart

The following chart shows an estimation of storage space used based on recording at one channel for an hour at a fixed bit rate.

Bit Rate	Storage Used
96K	42M
128K	56M
160K	70M
192K	84M
224K	98M
256K	112M
320K	140M
384K	168M
448K	196M
512K	225M
640K	281M
768K	337M
896K	393M
1024K	450M
1280K	562M
1536K	675M
1792K	787M
2048K	900M
4096K	1.8G
8192K	3.6G
16384K	7.2G




Please note that supplied values for storage space used is just for reference. The storage values in the chart are estimated by formulas and may have some deviation from actual value.

# Menu Operation

## Menu Structure

The menu structure is shown as follows. It varies according to different models.



The RS-232 and Hot Spare are not available for this series.

## Startup and Shutdown

Proper startup and shutdown procedures are crucial to expanding the life of the NVR.

### To start your NVR:

#### Steps:

1. Check the power supply is plugged into an electrical outlet. It is **HIGHLY** recommended that an Uninterruptible Power Supply (UPS) be used in conjunction with the device. The Power indicator LED on the front panel should be red, indicating the device gets the power supply
2. Turn on the power switch on the rear panel if the device starts up for the first time. The Power indicator LED should turn green indicating that the unit begins to start up.  
After the device starting up, the wizard will guide you through the initial settings, including modifying password, date and time settings, network settings, HDD initializing, and recording.


### To shut down the NVR:

#### Steps:

1. Enter the Shutdown menu.  
Menu > Shutdown



2. Select the **Shutdown** button.
3. Click the **Yes** button.
4. Turn off the power switch on the rear panel when the notice pops up.




## Setting the Admin Password

### *Purpose:*

For first-time access, you need to activate the device by setting an admin password. No operation is allowed before activation. You can also activate the device via Web Browser, SADP or Client Software.

### *Steps:*

1. Input the same password in the text field of **Create New Password** and **Confirm New Password**.




**STRONG PASSWORD RECOMMENDED**– We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security applications, resetting the password monthly or weekly can better protect your product.

2. Click **OK** to save the password and activate the device.



For the old versions, if you update it to the new version, the following dialog box will pop up once the device starts up. You can click **YES** and follow the wizard to set a strong password.



## Login and Logout


### User Login

**Purpose:**

If the NVR has logged out, you must login the device before operating the menu and other functions.

**Steps:**


1. Select the **User Name** in the dropdown list.



2. Input **Password**.
3. Click **OK** to log in.



The device gets locked for 60 seconds if the admin user performs 7 failed password attempts (5 attempts for the guest/operator).



### User Logout

**Purpose:**

After logging out, the monitor turns to the live view mode and if you want to do any operation, you need to enter the user name and password to log in again.

**Steps:**

1. Enter the Shutdown menu.  
Menu > Shutdown



2. Click **Logout**.



After you have logged out the system, menu operation on the screen is invalid. It is required to input a user name and password to unlock the system.

## Live View

Some icons are provided on screen in Live View mode to indicate different camera status. These icons include:

### Live View Icons


In the live view mode, there are icons at the upper-right corner of the screen for each channel, showing the status of the record and alarm in the channel, so that you can find problems as soon as possible.



Alarm (video loss, tampering, motion detection, VCA or sensor alarm)



Record (manual record, continuous record, motion detection, VCA and alarm triggered record)



Alarm & Record



Event/Exception (event and exception information, appears at the lower-left corner of the screen.)

## Adding IP Cameras

### *Purpose:*

Before you can get a live view or record video, you should add the network cameras to the connection list of the device.

### *Before you start:*


Ensure the network connection is valid and correct, and the IP camera(s) to add has already been activated.

Please refer to the User Manual for activating the inactive IP camera(s).

You can select one of the following three options to add the IP camera.

- **OPTION 1:**

### *Steps:*

1. Click to select an idle window in the live view mode.
2. Click the  icon in the center of the window to pop up the adding IP camera interface.

No.	IP Address	Amount of Channels	Device Model
1	10.16.1.14	0	
2	10.16.1.93	0	IP Dome

IP Camera Address: 10.16.1.14

Protocol: [ ]

Management Port: 8000

Transfer Protocol: Auto

User Name: admin

Admin Password: [ ]

Continue to Add

Buttons: Protocol, Search, Add, Back

- Select the detected IP camera and click the **Add** button to add it directly, and you can click the **Search** button to refresh the online IP camera list manually.

Or you can choose to custom add the IP camera by editing the parameters in the corresponding text field and then click the **Add** button to add it.

- OPTION 2:**

*Steps:*


- Select the **Add IP Camera** option from the right-click menu in live view mode or click Menu> Camera> Camera to enter the IP camera management interface.

Cam...	Add/De...	Status	Security	IP Camera A...	Edit	Upgrade	Camera Name
D1	[ ]	[ ]	Risk Password	10.16.1.93	[ ]	-	IPCamera 01
...	[ ]	[ ]	Active	10.16.1.93	[ ]	-	-
...	[ ]	[ ]	Active	10.16.1.14	[ ]	-	-
...	[ ]	[ ]	Active	10.16.1.205	[ ]	-	-
...	[ ]	[ ]	Active	10.16.1.216	[ ]	-	-

Buttons: Refresh, One-touch A..., Upgrade, Delete, One-touch A..., Custom Addi...

Net Receive Idle Bandwidth: 320Mbps

Exit

- The online cameras with same network segment will be detected and displayed in the camera list.
- Select the IP camera from the list and click the  button to add the camera. Or you can click the **One-touch Adding** button to add all cameras from the list.

- OPTION 3:**

*Steps:*


- On the IP Camera Management interface, click the **Custom Adding** button to pop up the Add IP Camera (Custom) interface.



2) You can edit the IP address, protocol, management port, and other information of the IP camera to be added.

3) Click **Add** to add the camera.

For the successfully added IP cameras(s), the Security status shows the security level of the password of each camera: strong password, weak password and risky password.



**Explanation of the icons**

Icon	Explanation	Icon	Explanation
	Edit basic parameters of the camera		Add the detected IP camera.
	The camera is disconnected; you can click the icon to get the exception information of the camera.		Delete the IP camera
	Play the live video of the connected camera.		Advanced settings of the camera.
	Upgrade the connected IP camera.	<b>Security</b>	Show the security status of the camera to be active/inactive or the password strength (strong/medium/weak/risk)

## Recording

### *Before you start:*

Make sure that the HDD has already been installed. If not, please install a HDD and initialize it. You can refer to the user manual for detailed information.





### *Purpose:*

Two kinds of record types are introduced in the following section, including Instant Record and All-day Record. And for other record types, you may refer to the user manual for detailed information.

## Instant Recording

On the live view window of each channel, there is a quick setting toolbar which shows on the bottom of the window when you click on it.



Click the  icon to enable record, and the icon turns to . And click  icon to disable the recording, then the icon turns to .

## All-day Recording


### *Steps:*

1. On the live view window, right lick the window and move the cursor to the **Start Recording** option, and select **Continuous Record** or **Motion Detection Record** on your demand.
2. And click the **Yes** button in the popup Attention message box to confirm the settings.  
Then all the channels will start to record in the selected mode.

## Playback

Play back the record files of a specific channel in the live view menu. Live Channel switch is supported.

### ● **Option 1:**

Choose a channel under live view using the mouse and click the  button in the shortcut operation menu.



Only record files recorded during the past five minutes on this channel will be played back.




● **Option 2:**

*Steps:*

1. Enter the Playback menu.

Mouse: right click a channel in live view mode and select Playback from the menu.



Under multi-screen live view, record files of the selected channel will be played back.

2. Playback management.

The toolbar in the bottom part of Playback interface can be used to control the playback functions.



Just check the channel or channels if you want to switch playback to another channel or execute simultaneous playback of multiple channels.


## Backup

Recorded files can be backed up to various devices, such as USB flash drives, USB HDDs or a DVD writer.

### Steps:

1. Enter Video Export interface.

Choose the channel(s) you want to back up and click on the **Quick Export** button.



2. Enter Export interface, choose backup device and click **Export** button to start exporting.



3. Check backup result.



## VCA Detection


### Purpose:

The NVR supports the VCA detection alarm (*face detection, vehicle detection, line crossing detection and intrusion detection, region entrance detection, region exiting detection, loitering detection, people gathering detection, fast moving detection, parking detection, unattended baggage detection, object removal detection, audio loss exception detection, sudden change of sound intensity detection, and defocus detection*) sent by IP camera. The VCA detection must be enabled and configured on the IP camera settings interface first.

### Steps:

1. Enter VCA Alarm interface of Camera Management and select a camera you want to detect VCA alarm.

Menu > Camera > VCA



2. Enable the VCA detection and configure the rule settings. Please refer to the *User Manual* for detailed instructions.

## VCA Search

The NVR supports the VCA search for behavior analysis, face capture, people counting and heat map.


**Face Search:** Search the captured face picture results triggered by face detection.

**Behavior Search:** Search and view the behavior detection (including line crossing detection, intrusion detection, unattended baggage detection, etc.) results in pictures and video files.

**People Counting:** Calculate the number of people entered or exited from a certain configured area and show in a chart of daily/weekly/monthly/annual report.

**Heat Map:** Analyze the visit times and dwell time of customers in a configured area. The heat map is a

graphical representation of data represented by colors.



## Accessing by Web Browser



You shall acknowledge that the use of the product with Internet access might be under network security risks. To mitigate network attacks and information leakage, please strengthen your own protection. If the product does not work properly, please contact with your dealer or the nearest service center.

### Logging In

You can get access to the device via web browser. You may use one of the following listed web browsers: Internet Explorer 6.0, Internet Explorer 7.0, Internet Explorer 8.0, Internet Explorer 9.0, Internet Explorer 10.0, Apple Safari, Mozilla Firefox, and Google Chrome. The supported resolutions include 1024\*768 and above.

#### Steps:

1. Open web browser, input the IP address of the device and then press Enter.
2. Login to the device.
  - If the device has not been activated, you need to activate the device first before login.

- 1) Set the password for the admin user account.
- 2) Click **OK** to login to the device.



**STRONG PASSWORD RECOMMENDED**– We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security applications, resetting the password monthly or weekly can better protect your product.

- If the device is already activated, enter the user name and password in the login interface, and click the **Login** button.

3. Install the plug-in before viewing the live video and managing the camera. Please follow the installation

prompts to install the plug-in.



You may have to close the web browser to finish the installation of the plug-in.

## Live View

The live view interface appears by default when you log into the device.



The live view interface may differ according to different models.

### Interface Introduction

No.	Name	Description
1	Channel List	Displays the list of channels and the playing and recording status of each channel.
2	Live View Window	Displays the image of channel, and multi-window division is supported.
3	Play Control Bar	Play control operations are supported.
4	PTZ Control	Pan, tilt, zoom operations are supported, as well as preset editing and calling. PTZ function can only be realized if the connected camera supports PTZ control.

The PTZ control is supported by certain series NVR.

### Start Live View

#### Steps:

1. In the live view window, select a playing window by clicking the mouse.
2. Double click a camera from the device list to start the live view.
3. You can click the button on the toolbar to start the live view of all cameras on the device list.

Refer to the following table for the description of buttons on the live view window:

Icon	Description	Icon	Description
	Select the window-division mode		Open/Close audio
	Start/Stop all live view		Start/Stop two-way Audio
	Capture pictures in the live view mode		Adjust volume
	Start/Stop all recording		Enable/Disable digital zoom
	Previous/Next page		Full screen
	Select different stream type for live view by clicking the icon : live view in main stream; : live view in sub stream;		

## Recording


### Before you start

Make sure the device is connected with an HDD or network disk, and the HDD or network disk has been initialized for first time to use.


Two recording types can be configured: Manual and Scheduled. The following section introduces the configuration of scheduled recording.


### Steps:


1. Click **Configuration > Storage > Schedule Settings** to enter Schedule Settings interface.
2. Select the camera to configure the record schedule.
3. Check the **Enable** checkbox to enable the recording schedule.




4. Choose the day in a week to configure the recording schedule.
  - 1) Click a day to set the start time and end time for recording.




- 2) Select the **Record Type** for the period. The record type can be Schedule, Motion, Alarm, Motion & Alarm, Motion | Alarm and Event.
- 3) Click **Save** to save the settings.
- 4) Click the  icon of the day to copy the settings of the current day to other days of the week if required.



- 5) Click **OK** to save the settings.
5. Click **Advanced** to configure advanced record parameters, and click the **OK** button to save the settings.



6. You can click  to configure advanced record parameters to copy the schedule of current camera to other cameras.
7. Click **Save** to activate the above settings.

## Playback



The playback interface may differ according to different models.

### Interface Introduction







No.	Name	Description
1	Channel List	Displays the list of channels and the playing status of each channel.
2	Playback Window	Displays the image of channel.
3	Play Control Bar	Play control operations are supported.
4	Time Line	Displays the time bar and the records marked with different colors.
5	Playback Status	Displays the playback status, including channel number and playback speed.
6	Calendar	You can select the date to play.


### Start Playback

#### Steps:


1. Click **Playback** on the menu bar to enter playback interface.
2. Click the camera from the device list for playback.
3. Select the date from the calendar and click **Search**.
4. Click the **Play** button to play the video file searched on the current date.
5. Use the buttons on the toolbar to operate in playback mode.

Button	Description	Button	Description
	Play/Pause		Stop
	Speed down		Speed up
	Play by single frame		Capture

Button	Description	Button	Description
	Stop all playback		Download
	Start/Stop video clipping		Open/Close audio
	Full screen		Reverse playback

6. You can drag the progress bar with the mouse to locate the exact playback point. You can also input the time in the textbox  and click  button to locate the playback point.

The color of the video on the progress bar stands for the different video types.



## Mobile Device Access

You shall acknowledge that the use of the product with Internet access might be under network security risks. To mitigate network attacks and information leakage, please ensure the network is protected. If the product does not work properly, please contact your dealer or the nearest service center.

### **Purpose:**

Once the device is configured on the network, and there are no restrictions in place preventing the recorder from accessing the internet, you can access the NVR from a mobile device to view live video as well as playback.

### **Steps:**

1. Download the "STGO2" application onto the mobile device(s) that will be accessing the DVR
2. Select the country it will be operated in, and select LOGIN
  - If the device has not been activated, you need to activate the device first.
  - This tutorial covers Cloud P2P connection, DDNS and direct IP are other options






Figure 4.3 Registration




Figure 4.4 Verification

3. Accept the terms of service, and select a registration method.
4. Verify the account using the code sent to either the email address or phone number used.




Figure 4.4 Add Device




Figure 4.5 QR Scan

5. Click on the "+" icon in the upper right corner, then scan the QR code displayed in the MENU>CONFIGURATION>NETWORK>ACCESS PLATFORM sub-menu of the DVR
6. You will then need to enter the Verification code on that same screen into the mobile app
7. Once added, you can now access Live/ Playback streams from the mobile device

**SECURITYTRONIX 2-Year Limited Stand Alone Digital Video Recorder Warranty**

Securitytronix. (the "Company") warrants to the Original Purchaser that the Stand Alone Digital Video Recorder is free from defects in workmanship or material under normal use. This warranty starts on the date of shipment of the hardware to the Original Purchaser. Any Hard Drive installed in the Stand Alone Digital Video Recorder is the warranty responsibility of the Hard Drive Manufacturer and is not covered by this or any other Securitytronix warranties. During the warranty period, the Company agrees to repair or replace, at its sole option, without charge to Original Purchaser, any defective component in the Stand Alone Digital Video Recorder. To obtain service, the Original Purchaser must return the Stand Alone Digital Video Recorder to the Company properly packaged for shipping. All defective products must be returned to the Company within thirty (30) days of failure. Products must be returned with a description of the failure and Return Merchandise Authorization (RMA) number supplied by the Company. To receive a RMA number and a return shipping address on where to deliver the hardware, call 610-429-1821. The shipping, and insurance charges incurred in shipping to the Company will be paid by Original Purchaser, and all risk for the hardware shall remain with the Original Purchaser until such time as Company takes receipt of the hardware. Upon receipt, the Company will promptly repair or replace the defective unit, and then return said unit to Original Purchaser, shipping prepaid. The Company may use reconditioned or like-new parts or units, at its sole option, when repairing any hardware. Repaired products shall carry the same amount of outstanding warranty as from original purchase. Any claim under the warranty must include dated proof of purchase or invoice. In any event, the Company's liability for defective hardware is limited to repairing or replacing the hardware. This warranty is contingent upon proper use of the hardware by Original Purchaser and does not cover: if damage is due to Acts of God (including fire, flood, earthquake, storm, hurricane or other natural disaster), accident, unusual physical, electrical, or electromechanical stress, modifications, neglect; misuse, operation with media not approved by the Company, tampering with or altering of the hardware, war, invasion, act of foreign enemies, hostilities (regardless of whether war is declared), civil war, rebellion, revolution, insurrection, military or usurped power or confiscation, terrorist activities, nationalization, government sanction, blockage, embargo, labor dispute, strike, lockout or interruption or failure of electricity, air conditioning, or humidity control, internet, network, or telephone service The warranties given herein, together with any implied warranties covering the hardware, including any warranties of merchantability or fitness for a particular purpose, are limited in duration to two years from the date of shipment to the Original Purchaser. Jurisdictions vary with regard to the enforceability of warranty limitations, and you should check the laws of your local jurisdiction to find out whether the above limitation applies to you. The Company shall not be liable to you for loss of data, loss of profits, lost savings, special, incidental, consequential, indirect, or other similar damages arising from breach of warranty, breach of contract, negligence, or other legal action even if the Company or its agent has been advised of the possibility of such damages, or for any claim brought against you by another party. Jurisdictions vary with regard to the enforceability of provisions excluding or limiting liability for incidental or consequential damages. You should check the laws of your local jurisdiction to find out whether the above exclusion applies to you. This warranty allocates risks of product failure between Original Purchaser and the Company. The Company's hardware pricing reflects this allocation of risk and the limitations of liability contained in this warranty. The warranty set forth above is in lieu of all other express warranties, whether oral or written. The agents, employees, distributors, and dealers of the Company are not authorized to make modification to this warranty, or additional warranties binding on the Company. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by the Company and should not be relied upon. This warranty gives you specific legal rights. You may also have other rights which vary from one jurisdiction to another.

For further assistance, or if you encounter any issue while using this product, please contact your distributor or Securitytronix at: 800-688-9282 Press 3 for support, then 2 for CCTV.