

DT-QAM-ENC-4-MPG2 and DT-QAM-ENC-8-MPG2 User Manual



Table of Contents

Introduction	3
Specifications	3
Safety Instructions	4
Unpacking and Handling.....	5
Installation	5
Front Panel	6
Rear Panel	6
Programming via Web Interface.....	7
Quick IP Ethernet Connection Guide.....	25
Common Troubleshooting.....	28
Warranty	29

Introduction

The **DT-QAM-ENC-4-MPG2** and **DT-QAM-ENC-8-MPG2** are HD encoder modulators featuring both H.264 and MPEG-2 encoding, enabling seamless integration with a wide range of television systems. Each input can be individually encoded and assigned to a different QAM channel, offering flexible broadcasting options. Configuration and management are simple through a user-friendly web-based interface.

Specifications

Input	
Input Connector	RJ45 - 1 GbE and HDMI - 8
Transport Protocol	UDP, RTP
Max Input IP Address	8
Input Transport Stream	MPTS and SPTS

Output					
Standard	DVB-C	DVB-T	ATSC	J.83B	DTMB
Bandwidth	6M	6, 7 or 8 M	6M	6 M	8 M
Constellation	64 QAM, 256 QAM	QPSK, 16QAM, 64QAM	8VSB	64 QAM, 256 QAM	QPSK, 16QAM, 32QAM, 64QAM QAM_4NR
Other Settings	Symbol Rate	Code Rate	—	—	Code Rate
	—	Guard Interval			Interleave
		2K, 4K, 8K			Sync Frame
		—			PN Phase

RF	
Output Level	≥ 45dBmV
Frequency Range	50-999.999 MHz
Out-band Rejection	≥60 dB
MER	Typ. 38 dB

General	
Power Consumption	60 W
Weight	8.2 lbs (3.71 kg)
Dimensions	12.52 x 10.24 x 1.73" (318 x 260 x 44 mm)
Language	English
Warranty	1-Year Limited Warranty

TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER FROM THIS UNIT. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING: TO PREVENT SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE



CAUTION

**RISK OF ELECTRIC SHOCK
DO NOT OPEN**

Safety Instructions

1. Read all safety and operating instructions before you operate the modulator
2. Retain all safety and operating instructions for future reference
3. Heed all warnings on the modulator and in the safety and operating instructions
4. Follow all installation, operating and use instructions.
5. Unplug the modulator from the AC power outlet before cleaning. Use only a damp cloth for cleaning the exterior of the modulator
6. Do not use accessories or attachments not recommended by us, as they may cause hazards, and will void the warranty
7. Do not operate the modulator in high-humidity areas, or expose it to water or moisture.
8. Do not place the modulator on an unstable cart, bracket or table. The modulator may fall, causing serious personal injury and damage to the modulator. Install the modulator only in a mounting rack designed for 19" rack-mounted equipment.
9. Do not block or cover slots and openings in the modulator. These are provided for ventilation and protection from overheating. Never place the modulator near or over a radiator or heat register.
10. We strongly recommend using an outlet that contains surge suppression or ground fault protection. For added protection during a lightning storm, or when the modulator is left unattended for long periods of time, unplug it from the wall outlet or PDU and disconnect the lines between the modulator and its source. This will prevent damage caused by lightning or power line surges.
11. Do not overload wall outlets or extension cords, as this can result in a risk of fire or electrical shock.
12. Never insert objects of any kind into the modulator through openings as the objects may touch dangerous voltage and will void the warranty. Refer all servicing to authorized service personnel.
13. Unplug the modulator from the wall outlet or PDU and refer servicing to authorized service personnel whenever the following occurs:
 - The power supply cord or plug is damaged
 - Liquid has been spilled into or objects have fallen into modulator
 - The modulator has been exposed to rain or water
 - The modulator has been dropped or the chassis has been damaged
 - The modulator exhibits a distinct change in performance

When replacement parts are required, ensure that the service technician uses replacement parts specified by us.

Unpacking and Handling

A full DT-QAM-ENC-4-MPG2 or DT-QAM-ENC-8-MPG2 is shipped with all equipment assembled, wired, factory tested, and then packaged in an appropriate shipping container.

- DT-QAM-ENC-4-MPG2 or DT-QAM-ENC-8-MPG2 digital modulator (QTY=1)
- Power Cord and 3-pin plug (QTY=1)

Mechanical Inspection

Inspect the front and rear of the equipment for shipping damage. Make sure the equipment is clean, and no wire, cable, or connectors are broken, damaged or loose.

Precautions

- Avoid heat buildup
- Ensure easy access to rack wiring
- Facilitate servicing and maintenance
- Avoid direct heating or air conditioning
- Make sure rack supports are sufficiently rigid to support racks
- Beware of dripping water onto equipment from leaky roofs, waveguide roof entries and cold water pipe condensations

Damage in Shipment

Should any damage be discovered after unpacking the unit, immediately contact DataTronix at 800-688-9282.

Installation

The DT-QAM-ENC-4-MPG2 or DT-QAM-ENC-8-MPG2 is designed to be installed in a rack shelf or a standard rack. Please follow the instructions below to install the DT-QAM-ENC-4-MPG2 or DT-QAM-ENC-8-MPG2 digital modulator:

1. Connect the power plug to the jack
2. Connect the video source to the DT-QAM-ENC-4-MPG2 or DT-QAM-ENC-8-MPG2 modulator
3. Connect the DT-QAM-ENC-4-MPG2 or DT-QAM-ENC-8-MPG2 to your laptop or computer
4. Power up the modulator

DT-QAM-ENC-4-MPG2 Front Panel View



1. **PWR** Indicate power on.
2. **RUN** The light will keep flashing when system is on.
3. **DT-QAM-ENC-4-MPG2**: CH1-CH4/ **DT-QAM-ENC-8-MPG2**: CH1-CH8
4. **DATA IN**: IP signal input port at 1000M
5. **NMS** - Net management system port
[IP:192.168.1.30; USER NAME: user ; PASSWORD: user]
6. **DEFAULT** - Press for 10 seconds to restore the encoder to the factory setting \ (Like the network setting and PID settings)

Rear Panel View



7. **HD INPUT PORTS**: Feed the HDMI signals into the modulator.
(4 HD Input on DT-QAM-ENC-4-MPG2/ 8 HD Input on DT-QAM-ENC-8-MPG2)
8. **RF OUT**: 40dBmV maximum output is provided at this port
9. **TEST**: Output level read at this point will be down 20dB from the actual output
10. **POWER CORD**: 12V 5A power source
11. **ON/OFF SWITCH**: Turns the unit on or off
12. **GDN**: For modulator grounding

WARNING:

For the protection of your equipment and its proper working, it is necessary to connect the DT-QAM-ENC-4-MPG2 / DT-QAM-ENC-8-MPG2 to a ground connection.

Web Management

Login:

The DT-QAM-ENC-4-MPG2 / DT-QAM-ENC-8-MPG2 has a user friendly interface for programming and monitoring the device. The user can access to the built-in web UI by logging into Google Chrome, Firefox or Microsoft Edge accounts. (The best browsers)


DT-QAM-ENC-4-MPG2 / DT-QAM-ENC-8-MPG2 Setup Instructions

1. Connect the **DT-QAM-ENC-4-MPG2** or **DT-QAM-ENC-8-MPG2** to your computer or laptop using an Ethernet cable via the **NMS** port.
2. Power on the modulator and wait approximately 2 minutes until the **RUN** indicator remains steady.
3. Open your web browser and log in to the modulator using the default IP address:
192.168.1.30.

The default user name and the default password are the following:

Username: **user**

Password: **user**



NOTE:


Please make sure your computers IP address is in the same subnet as the modulator.

Reminders:

1. Please change the user name and password if needed.
2. Username/password are case-sensitive and may contain letters or numbers.
3. Username/password must be a minimum of 1 byte and a maximum of 32 bytes in length.

System Page:

This page is a read-only one which displays the general health of the unit, such as temperature, Input and output ports and Serial number. The information is provided as a quick way to monitor the system or assist with troubleshooting issue.



Serial Number: The unique ID for this modulator.


Software Version: If there's something wrong with this device, please send this information to us.

Modulation: Indicates the RF output modulation.


Temperature: Indicates the CPU working temperature in real-time.

Rear Panel: Indicates the input connector status. The green color means the HDMI cable is well connected while the gray means disconnected.

Cooling Fans: There are four cooling fans installed in the left side of the case.



The fan is working.



The fan is down. Please replace it.

Front Panel: Indicates the IP input (1000M) and NMS status (100M).

ON-CLOUD State: Green for connecting with the Cloud server. Grey means disconnection.

Input: Set up the input parameters

Route: Select the output channels/services.

Output: View the output channels and set up the modulation parameters.

System: System settings: Network/ Account/ System/ Time and Date/ Cloud

Input Settings - IP:




NO.	IP Address	Port	Bitrate(Kbps)
1	239.0.0.1	1234	66263.23
2	239.0.0.2	1234	52597.89

1. Click the **+Add** button to add an IP address.
2. In most cases, select **Multicast** and enter the desired IP address.
3. Click **Submit**. The system will analyze the IP stream and display the available programs in the Router section.

To Delete an IP Address:

Check the box next to the IP address you wish to remove, then click **Delete**.



Unicast: Select to input the unicast streams. Normally it is the same like the output port.

Multicast: Select to input the multicast streams. Normally it starts with 239.

From: A read-only information.

IP Address: Input the IP address. When you select unicast, please change the IP in SYSTEM>-NETWORK>ETH1.

Port: Input the port number.

Step Mode: IP address: Only Change the Ip Address

Port: Only change the Port

IP address +Port: Changes the Ip Address and the Port

Step Times: The system will add 1 to the IP address or port according to the Step mode. The max value is 10.

Count: The system will generate the IP address according to the count value. The max value is 256.

HDMI Signal


IP		HDMI								
NO.	Status	Channel	Enable	Input Resolution	Out Resolution	Service Name	Video Format	Audio Format	Set Bitrate(Kbps)	Real Bitrate(Kbps)
1		1-1	☒	1920X1080_59P	1920X1080_30P	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	8473.54
2		1-2	☒	1920X1080_59P	1280X720_60P	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	7811.78
3		1-3	☒	1920X1080_59P	1920X1080_30P	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	8091.52
4		1-4	☒	1920X1080_59P	1920X1080_30P	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	8434.43
5		2-1	☒	UNKNOWN	UNKNOWN	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	0.00
6		2-2	☒	UNKNOWN	UNKNOWN	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	6786.05
7		2-3	☒	UNKNOWN	UNKNOWN	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	6786.05
8		2-4	☒	UNKNOWN	UNKNOWN	DTV	H264_VIDEO_STREAM	MPEG_AUDIO	8000	6665.73

Status	A green light indicates the port is active and working properly. A gray light indicates an issue or an unused port.
Channel	Displayed as Slot-Port (e.g., 1-1). The first number refers to the slot number, and the second number refers to the input port within that slot.
Enable	Use this option to enable or disable the HDMI input port.
Input Resolution	Displays the detected input resolution. If it shows "Unknown," the resolution is not supported.
Output Resolution	Allows you to downscale the input resolution as needed.
Service Name	Enter the desired service name here.
Video Format	For this device, it only supports H.264
Audio Format	Select from MPEG1, AAC-LC-ADTS, AAC-LC-LATM, or AC3.
Set Bitrate	Configure the output bit rate here. Maximum allowed bit rate is 20,000 Kbps.
Real Bitrate	Displays the actual current output bit rate

NOTE:

For broad compatibility, it is recommend to use AAC-LC-ADTS. For efficient transmission, you might choose AAC-LC-LATM.

Router Settings




The screenshot displays the Router Settings interface. At the top, there are eight bandwidth progress bars for RF channels RF1 through RF8, each showing frequency and bandwidth usage. Below these is a control bar with buttons for 'Cancel Forwarding' and 'Quick Setting', along with filters for 'Show' and 'RF Channel'. The main section is a table listing services and channels, including IP ETH1 and HDAM1 entries. At the bottom, there is a summary bar showing 'Total programs: 164', 'Forwarded programs: 27', and 'Not forwarded programs: 137'.

The router setting is the most important in this modulator. This is where you are able to view all input channels, and forward to output frequencies


1	Bandwidth Progress Bar
2	Quick setting and List Filter
3	Service/Channel List
4	Service/Channel Information

Bandwidth Progress Bars



The progress bar will move as the user sends programs to the frequency. We recommend utilizing no more than 80% of the total bandwidth, indicated by the gray zone. Once usage exceeds 80%, the bar will change from green to red as a warning signal.

RF Number	It could be 4RF or 8RF according to your order.
Frequency	Change the frequency in the output settings.
Used bandwidth/ Total Bandwidth	The total bit rate of your selected services/ Total bandwidth you can use.
Bandwidth usage percentage	Precisely express the used bandwidth in percentage.




Green Bar:

Additional channels or services can be added to this frequency, as the current data rate usage is low.



Grey Bar Covered:


The data rate has reached the maximum recommended limit. To maintain stable operation, no additional services should be added to this frequency.



Red Bar:

The recommended data rate has been exceeded, which may cause data overflow. This can result in distorted images or a complete loss of service on the affected channel.


Information Filter




Since the router list may contain a large amount of information, a filter is provided to help manage channels and services more efficiently.

Simply select the input type or output frequency type from the drop-down menu, and the system will display the corresponding information based on your selection.

Cancel Forwarding	Cancel all the forwarded channels/services in the router list.
Quick Setting	Forward the selected channels/services to a desired frequency.



Router List



View all input streams and assign programs to preset frequencies using the Forward button. Keep the Progress Bar below 80% to avoid picture issues.

Steps:

1. Find your desired services
2. Select an RF channel
3. Click Forward to assign services

☐	This checkbox is used to quickly select the stream under unfolded stream title
Type	The input stream type : IP,HDMI
Slot	The stream's input slot. E.g. : 0-5 means the IP input and this is the 5th IP address.
Service Name	The service's original name.
State	Green :signal is locked; Orange: PSI is changed; Red: The stream is lost.
CA	: This is a free to view service; : This is an encrypted service.
RF Channel	Choose the RF output channel for the selected stream. To change the frequency, navigate to OUTPUT > RF SET > Frequency.
Action	Forward: use this service; Cancel : No use this service
	: Unfold the stream details; : Fold the stream details.
	Common PID Edit: Modify program number, service name, provider, LCN, etc.*
	Timeout setting/ CA filtering enable / PID remapping. *
	PSI/SI viewer. It will display the PSI/SI table here.*
	Refresh. This ICON only appears in IP stream and satellite stream.

* View more information in next page.

IP ETH1 239.0.0.1:1234 (13/31)

The forwarded services number in blue.

The total services number that this stream contains in black.

Stream Information

 **Total programs: 9**  **Forwarded programs: 1**  **Not forwarded programs: 8**

This information is a summary of the router list, which is very helpful to the operators.

Edit (Slot: 0-1)

Program Information

Destination PID

Service Number: 11

Service Name: Nick Jr

Service Provider: NEXPARABOLA

Source PID

Service Number: 17

Service Name: Nick Jr

Service Provider: NEXPARABOLA

Destination PID : Read from the source PID. It is recommended to modify the PID in the OUTPUT>CHANNEL LIST.

Source PID : Analysis data from the source.

Enable : select the PID you need.

NO.	SRC PID	Type	DEST PID	TS Type	Enable
1	317	PMT PID	352		
2	517	PCR PID	353		
3	517	AVC(H264)	353	18 hex	☒
4	717	Mpeg-1 Audio	354	3 hex	☒
5	917	Mpeg-1 Audio	355	3 hex	☒
6	3017	ECM	356		☒
7	2017	ECM	357		☒

Setting

Timeout Setting: 5 s

Range: 5 ~ 120s

CA Filtering: ☒

PID Mapping: ☒

Timeout Setting

The system will stop analyzing the stream according to your input time.

CA Filtering


☒ : Filter the EMM information.
☐ : Pass through the EMM information.*

PID Mapping

☒ : The system will generate PID to every stream.*
☐ : Use the source PID.
 We recommend to keep it on to avoid PID conflict.

Cancel Submit

PSI/SI




PSI/SI VIEWER

PSI	The PSI data is structured as PAT,PMT and SDT.
PAT	Program Association Table : for each service in the multiplex, the PAT indicates the location PID values of the TS of the corresponding PMT.
PMT	Program Map Table : the PMT identifies and indicates the locations of the streams that make up each service and the location of the Program Clock Reference fields for a service.
SDT	Service Description Table : the SDT contains data describing the services in the system e.g. names of services, the service provider, etc.

Output

Channel List: In the OUTPUT page, we can reschedule the channels/services and PID in a much easier way.



Channel List interface showing a table of channels. The table has columns: NO., Source, RF Channel, Service Number, Service Name, Service Number, Short Name (D), Major Number, Minor Number, and Action. The first two rows are expanded, showing details for RF 1 (474.000 MHz) and RF 2 (482.000 MHz).

NO.	Source	RF Channel	Service Number	Service Name	Service Number	Short Name (D)	Major Number	Minor Number	Action
1	HDMI(1-1)	RF1 (474.000)	1	DTV	1	DTV	0	0	[Edit] [Delete]
2	HDMI(1-2)	RF1 (474.000)	1	DTV	2	DTV	0	0	[Edit] [Delete]
RF 2 (482.000 MHz) 0.01/26.97 Mbps (0)									
RF 3 (490.000 MHz) 0.01/26.97 Mbps (0)									
RF 4 (498.000 MHz) 0.01/26.97 Mbps (0)									
RF 5 (506.000 MHz) 0.01/26.97 Mbps (0)									
RF 6 (514.000 MHz) 0.01/26.97 Mbps (0)									
RF 7 (522.000 MHz) 0.01/26.97 Mbps (0)									
RF 8 (530.000 MHz) 0.01/26.97 Mbps (0)									


Delete	Delete the selected service.
Submit	Submit the updated service.
☐	This checkbox is used to quickly select the stream under unfolded stream title
Source	The input stream type : IP,DVBS/S2
RF Channel	Select a output RF channel for the desired service. To modify it, please go with OUTPUT>>RF SETTING>>Frequency
Service Number	To create a service list. But this function has to be supported by the set-top-box.
Short Name	Input the short name here.
Major Number	Major number input value range is 0 to 1023.
Minor Number	Minor number input value range is 0 to 1023.
 	 : Unfold the stream details;  : Fold the stream details.
	Common PID edit : Service number/Service name/Provider...
	Delete this service.

NOTE:

If there's any change applied in service number/service name, Major number or Minor number, please tick the checkbox and press Submit to save. Otherwise, the change won't be applied to the system.

RF Setting

In this page, you can set up the output modulation with its parameters and the output frequencies.



Modulation


ATSC	
Bandwidth	Select ATSC channel bandwidth from 6/7/8MHz. 6MHz for the regular output data rate.
Constellation	8VSB
IQ SW	IQ Swap ensures the demodulator interprets the constellation correctly.
Symbol Rate	The symbol rate is fixed in 10760 KS/s.
J.83B	
Bandwidth	Select QAM channel bandwidth from 6/7/8MHz. 6MHz for the regular output data rate.
Constellation	Select the signal modulation 64/256QAM
Symbol Rate	The symbol rate is fixed in 5057 KS/s.

RF Settings

CH Input Mode	Choose the input frequency mode from Input from List or Manual input.
RF Enable	Enable or disable the channel (A gap of the selected bandwidth occurs)
Frequency	Two bonded output channel blocks 1-4 and 5-8. Set the start output frequency of block 1 by setting channel 1 and the start output frequency of block 2 by setting channel 5. All further channels will be set automatically according to the bandwidth.
TSID	Transport Stream ID (Requires a unique number for each channel).
ONID	Allocating the Original Network ID (Identifier of the provider).
Network ID	In local Cable TV system, this is an optional ID. You can input any value as you like.
Network Name	Input the network name.
	Input private data
	PAT/PMT/SDT/NIT/CAT/EIT/TDT/TOT table insertion
Attenuation	Reduce the RF output level


 Any changes applied here requests SUBMIT to save.***

Basic Settings



The screenshot shows the 'Basic Parameters' settings page. At the top, there is a navigation bar with tabs: 'Basic Parameters' (selected), 'Network', 'Account', 'System', 'Time And Date', and 'CLOUD'. Below the navigation bar, the 'Basic Parameters' section is expanded, showing two input fields: 'Device Name' with the value 'SKD711X' and 'SDT Character Set' with a dropdown menu set to 'GBK'. A 'Submit' button is located at the bottom of the form.

Network Settings




NMS	
IP address, Subnet mask, Gateway, Primary and Secondary DNS	These are network parameters of the management network interface of the SKD711X device, which can be changed as required.
MAC Address	MAC address of the management network interface of the DT-QAM-ENC-** device.
ETH1 (Data In)	
IP Address	The IP address for this port, which is related when it is used under Unicast mode.
MAC Address	MAC address of the input network interface of the DT-QAM-ENC-** device.
IGMP Version	If your input IP stream contains IGMP, please select the right version to match the input stream.

NOTE:

1. Making changes in this area can affect the system communication. --PROCEED WITH CAUTION!!!
2. Management in IP address should only be changed when it is necessary to manage the entire system from a different subnet. Otherwise, please leave what it is.

Account




The screenshot shows a web interface for account management. At the top, there is a navigation bar with tabs: Basic Parameters, Network, Account (selected), System, Time And Date, and CLOUD. Below the navigation bar, there are two main sections: 'Current User Information' and 'New User Information'. The 'Current User Information' section contains two input fields: 'Current Username' and 'Current Password'. The 'New User Information' section contains three input fields: 'New Username', 'New Password', and 'Confirm Password'. A 'Submit' button is located at the bottom of the 'New User Information' section.

To verify the username and the password, please input your current username and password.
Please notice that they are both case-sensitive.

If you forget your new username or new password, you can use the reset button in the front panel to restore.

System



The screenshot displays a web interface for system management with the following sections:

- Upgrade System from file:** Includes a text instruction, a file selection area with a "Browse" button, and an "Upgrade" button.
- Restore to factory settings:** Includes a text instruction and a "Restore" button.
- Reboot:** Includes a text instruction and a "Reboot" button.
- Export Settings:** Includes a text instruction and a "Backup" button.
- Import Settings:** Includes a text instruction, a file selection area with a "Browse" button, and a "Restore" button.

Upgrade system from file: Upgrade the modulator with the latest software.

Restore to factory settings: The restore function will recover the input and output settings and the IP address to the factory mode.

Reboot: To reboot the modulator.

Export Settings: Back up the input and output settings to your computer.


Import Settings: Recover the settings to the modulator from your computer.

NOTE:

Another way to restore the settings:


Press the default button in the front panel for 10 seconds. If you see the running light is flashing, that means the restore is completed.

Time and Date



Enable NTP ☒	
NTP Server	Input the NTP server address which is best for you. Make sure the NMS port is connected with the Internet.
Local Timezone	Select a timezone
Enable NTP ☐	
Time And Date	Press the TODAY button, and the modulator will read the time and date from your computer.
Local Timezone	Select a timezone

Cloud



Cloud Link

CLOUD Enable	Tick on the checkbox to activate the cloud service
Alarm Enable	Tick on the checkbox to activate the alarm service
Server Address	Input the CLOUD server address or the domain name
Server Port	Input the CLOUD server
Submit	Press submit to save the information

Add to your Cloud account


Binding Status	Green for connecting with the Cloud server. Grey means disconnection.
Username	Your CLOUD account name.
Password	Your CLOUD password
Submit	Press submit to save. A manual reboot is requested to activate the settings.

Quick IP Ethernet Connection Guide


NOTE:

Make sure you login your operation system as the administrator.


1. Go to “Windows Start” 




2. Go to Windows Settings
3. Go to “Network & Internet”
4. Go to “Ethernet” on the left side of the menu




5. Go to “Change adapter options”



6. Double click on the Ethernet Source or Right Click and select “Properties”




7. Open Properties




8. Go to “Internet Protocol Version 4 (TCP/IPv4)”

9. Go to “Properties”



10. Go to “Use the following IP address”




11. Set IP address


Set IP address: 192.168.1.10

Set Subnet mask: 255.255.255.0

Set Default gateway: 192.168.1.1



12. Save all the settings.



Common Troubleshooting

Symptom	Recommended Action
Power LED is not lit.	Check the power cord connection
Can't login to the NMS	Check Chapter 10
The WEB UI is not in order and can't save the settings	Clear your browsing data
CH1 to CH8 LED are not lit	Power on the input video device
	Check the HDMI cable
	Check the input video resolution
Unknown shown in the input resolution	No video input
	No supported video resolution
Other issue	Please contact us for technical support



Warranty

DATATRONIX 1-Year Limited Warranty

DATATRONIX. (the “Company”) warrants to the Original Purchaser that the item purchased is free from defects in workmanship or material under normal use. This warranty starts on the date of shipment of the hardware to the Original Purchaser.

During the warranty period, the Company agrees to repair or replace, at its sole option, without charge to Original Purchaser, any defective component. To obtain service, the Original Purchaser must return the item to the Company properly packaged for shipping. All defective products must be returned to the Company within thirty (30) days of failure. Products must be returned with a description of the failure and Return Merchandise Authorization (RMA) number supplied by the Company. To receive a RMA number and a return shipping address on where to deliver the hardware, call 610-429-1821. The shipping, and insurance charges incurred in shipping to the Company will be paid by Original Purchaser, and all risk for the hardware shall remain with the Original Purchaser until such time as Company takes receipt of the hardware. Upon receipt, the Company will promptly repair or replace the defective unit, and then return said unit to Original Purchaser, shipping prepaid. The Company may use reconditioned or like-new parts or units, at its sole option, when repairing any hardware. Repaired products shall carry the same amount of outstanding warranty as from original purchase. Any claim under the warranty must include dated proof of purchase or invoice. In any event, the Company's liability for defective hardware is limited to repairing or replacing the hardware.

This warranty is contingent upon proper use of the hardware by Original Purchaser and does not cover: if damage is due to Acts of God (including fire, flood, earthquake, storm, hurricane or other natural disaster), accident, unusual physical, electrical, or electromechanical stress, modifications, neglect, misuse, operation with media not approved by the Company, tampering with or altering of the hardware, riot, war, invasion, act of foreign enemies, hostilities (regardless of whether war is declared), civil war, rebellion, revolution, insurrection, military or usurped power or confiscation, terrorist activities, nationalization, government sanction, blockage, embargo, labor dispute, strike, lockout or interruption or failure of electricity, air conditioning, or humidity control, Internet, network, or telephone service.

The warranties given herein, together with any implied warranties covering the hardware, including any warranties of merchantability or fitness for a particular purpose, are limited in duration to one year from the date of shipment to the Original Purchaser. Jurisdictions vary with regard to the enforceability of warranty limitations, and you should check the laws of your local jurisdiction to find out whether the above limitation applies to you.

The Company shall not be liable to your for loss of data, loss of profits, lost savings, special, incidental, consequential, indirect, or other similar damages arising from breach of warranty, breach of contract, negligence, or other legal action even if the Company or its agent has been advised of



the possibility of such damages, or for any claim brought against your by another party. Jurisdictions vary with regard to the enforceability of provisions excluding or limiting liability for incidental or consequential damages. You should check the laws of your local jurisdiction to find out whether the above exclusion applies to you.

This warranty allocates risks of product failure between Original Purchaser and the Company. The Company's hardware pricing reflects this allocation of risk and the limitations of liability contained in this warranty. The warranty set forth above is in lieu of all other express warranties, whether oral or written. The agents, employees, distributors, and dealers of the Company are not authorized to make modification to this warranty, or additional warranties binding on the Company. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by the Company and should not be relied upon.

This warranty gives you specific legal rights. You may also have other rights which vary from one jurisdiction to another.