



CT-STB-DVR-RC

Remote Control Setup Guide


1. Press and hold the “OK”(see image on back #1) and “0” buttons simultaneously for 3 seconds to enter learning mode; the light will remain on. If there is no activity within 10 seconds, or if you press and hold “OK” and “0” again, the light will turn off and exit learning mode.
2. Press the Power button on the TV control panel (see image on back #2). The light will flash once and then remain steadily on.
3. Place the original TV remote control and the CT-STB-DVR-RC remote control 1-2 inches (3-5 cm) apart. Press the Power button on the original TV remote control. The light will flash twice slowly and then stay steadily on, indicating that learning was successful.
4. Repeat steps 2 and 3 to program additional buttons.
(see image on back #3, #4,)
 - #3 Volume Buttons
 - #4 TV Source Button
5. Once learning is complete, press any button that was not programmed, or remain inactive for 10 seconds. The light will flash twice and then turn off, indicating that the data has been saved and the system has exited learning mode.



CT-STB-DVR-RC

Remote Control Setup Guide

- 2 Power button on the TV control panel
- 3 Volume buttons on the TV control panel



- 1 OK Button
- 4 Source Button on the TV control panel

800-688-9282

sales@nace.tv | nace.tv