

FT-EMCU-1G-SM-DX-MINI-KIT

User Manual

Industrial Mini Gigabit Media Converter, Dual Optical Ports

Fiber Optic 10/100/1000Mbps
Ethernet Transmission System



Model Number: FT-EMCU-1G-SM-DX-MINI-KIT
Industrial Mini 10/100/1000Mbps Ethernet Media Converter





Table of Contents

1.0	Safety Instructions.....	3
2.0	Fiber Installation Tips.....	4
3.0	Product Description.....	5
4.0	Product Features.....	5
5.0	Product Signal Format & Specification	6
6.0	Front Panel Pin-out Assignment Diagram.....	7
7.0	Front Panel and Rear Panel LED Indicators.....	8
8.0	FiberTronix 1-Year Limited Warranty.....	9-10

1.0 Safety Instructions

The safety information contained in this section, and on other pages of this manual, must be observed whenever this unit is operated, serviced, or repaired. Failure to comply with any *precaution*, *warning*, or instruction noted in the manual is in violation of the standards of manufacture, warranty and intended use of the unit. NACE assumes no liability for the customer's failure to comply with any of these safety requirements.

**LASER RADIATION CAUTION:
DISCONNECTED OPTICAL CONNECTORS MAY EMIT OPTICAL ENERGY.
DO NOT VIEW BEAM WITH OPTICAL INSTRUMENTS (MAGNIFIERS).**

This product contains Class 1M lasers

- Class 1M laser product according to IEC60825-1:1993+A1+A2
- **CAUTION: Use of controls or adjustments or procedures other than those specified herein may result in hazardous radiation exposure.**
- **Precautions should be taken to prevent exposure to optical radiation if the internal PCB removed from its enclosure or when the fiber is disconnected from the unit.**
- Laser radiation may be present on a fiber connection to this unit even when the power has been removed from the unit.
- This unit is intended for installation in locations where only trained service personnel have access to the fiber connections.
- The optical connectors are listed in the Connection Diagrams and Function section of this manual.
- Optical outputs and wavelengths are listed in the Specifications section of this manual.

The optical devices used in this equipment are Hazard Level 1M. As required by IEC60825-1, the installer is responsible for insuring that the label depicted below is present in the restricted locations where this equipment is installed.



This assembly contains parts sensitive to damage by electrostatic discharge (ESD).

Use ESD precaution procedures when touching, removing or inserting parts or assemblies.



Units are not waterproof; please install in an appropriate NEMA Enclosure.

When units are installed in extremely hot environments, the metal enclosures may become hot to the touch. Please install in restricted areas where properly trained personnel have access.

2.0 Fiber Installation Tips

Fiber Information

Units are manufactured with optical connector covers to keep them from accumulating dirt. In addition to safety precautions, our manual also provides the following guidelines when working with optical fibers.

Please maintain optical fiber connectors as clean as possible to reduce loss of optical transmission output. Cleanliness is extremely important to proper operations.

1. Protect optical connectors by leaving the connector covers in place on unused fiber connections and on the fiber tips themselves.
 - a. Personnel who remove and replace fiber connectors or fiber pigtails should be equipped with a fiber cleaning kit. These are available as off-the-shelf items from a supplier of fiber optic accessories.
 - b. Isopropyl Alcohol and lint-free tissue or cloth may be used to clean fiber connector tips.
 - c. Do not use rubbing alcohol mixed with water. This can cause additional spots.
 - d. Clean the fiber by pulling the connector tip across the tissue, then turn the connector 90 degrees and repeat it in a different spot on the tissue.
 - e. Don't pull the fiber across and then push it back. This will put the dirt that was cleaned off back on again.
 - f. Repeat the process on a dry, folded tissue.
2. When removing fiber cables from fiber system ports, it is good practice to clean them again.
3. Installer must pay attention to the bend radius of the fibers. A general rule is to have a 3-inch (8cm) bend radius. A bend radius less than 3 inches may cause attenuation also known as optical signal loss.
4. Installers of fiber equipment should be equipped with an Optical Light Source an Optical Power Meter to measure the optical inputs and outputs in a system. These instruments are available from Alba at great savings, especially to our customers. The use of these tools will save much time and effort in getting optical communications links up and running. Properly equipped and trained installers can quickly determine the source of any problems that occur.

3.0 Product Description

The Series FT-EMCU-1G-SM-DX-MINI-KIT are mini media converters, designed to transmit and receive 10/100/1000Mbps data over one or two optic fibers. Units feature includes half or full duplex mode, auto-Negotiation from 10Mbps, 100Mbps and 1000Mbps Ethernet rate without adjustments. The optical interface operates at a 1000Mbps rate. The FT-EMCU-1G-SM-DX-MINI-KIT Series are environmentally hardened to operate in extreme temperatures. Features contain low power consumption, LED indicators for monitoring equipment link and performance operating status and auto resettable voltage transient fuses. The series FT-EMCU-1G-SM-DX-MINI-KIT are outstanding products for transmission of 10/100/1000Mbps Ethernet signals..

4.0 Product Features

- Mini Size Industrial Media Converter
- 10/100/1000Mbps Ethernet
- Electrical Port Supports Auto-Negotiation for 10Mbps, 100Mbps or 1000Mbps,
- Full or Half Duplex Mode
- Optical Port Supports 1000Mbps Full Duplex Data
- Automatic MDI/MDI-X Crossover Cables
- Transparent to Data Encoding / Compatible with Major Data Protocols;
- IEEE 802.3 compliant.
- Performance and Link Status Indicator LEDs
- Voltage Transient Protection on Power / Signals
- Single or Dual fiber Versions, SC
- Auto Resettable Fuses on Power Lines
- Designed with Lowest Power Consumption
- 12VDC Input Voltage (Standalone) for non PoE
- Compliance with CE, FCC
- Environmentally Hardened to Operate in Extreme Temperatures.

5.0 Product Signal Format & Specifications

Connectors

Optical	SC, Double Fiber
Power	Terminal Block
Ethernet	RJ45

Optical Parameter

Fiber	Multimode
Wavelengths (MM)	1310/1550nm
Wavelengths (SM)	1310/1550nm

Data

Data Interface	Ethernet
Data Rate	10/100/1000 Mbps IEEE 802.3 Compliant Full Duplex or Half Duplex Electrical Port / Full Duplex Optical Port

Properties

Switching delay	≤1.372us
MAC address table	1K
Buffer	1Mb

Interface

Fiber Port	1×1000 Base-X Fiber port
RJ45 Port	1×10/100/1000Base-T Copper Ports, support MDI/MDIX
LED	Power, SYSTEM, LINK/ACT

Power Parameter

Input	12V DC (non PoE)/48V DC (PoE)
Power	1.4W
Power Consumption	9W Max
Current Protection	Auto Resettable Solid –State Current Limiters
Power port	DC Adapter

Mechanical Property

Case	Aluminum alloy, IP30 Rate
Dimension	3.27 x 1.98 x 1.02" (80.0 × 51.5 x 27.1mm)
Weight	<1.3lbs (600g)
Installation	Wall-mounted/ Din-Rail selectable
Operating Temperature	-40 - 167°F (-40 - 75°C)
Storage Temperature	-49 - 203°F (-45 - 95°C)
Operating Humidity	5 - 95% (No condensation)
MTBF	> 100,000 hrs
Warranty	1-year Limited Warranty

6.0 Dimensions of FT-EMCU-1G-SM-DX-MINI-KIT and Panels Layout

Figure 1 below shows the dimensions of FT-EMCU-1G-SM-DX-MINI-KIT.

Figure 2 below shows the Panel Layout.




Fig. 6.1





Fig. 6.2

7.0 Front Panel LED Indicators

All the media converters have panel mounted indicators to provide visual operational status of each slot. Below are listed and described the functions of the various LED indicators.

FT-EMCU-1G-SM-DX-MINI-KIT LED STATUS INDICATORS





8.0 FiberTronix 1-Year Limited Warranty

FIBERTRONIX. (the "Company") warrants to the Original Purchaser that the item purchased is free from defects in workmanship or material under normal use. This warranty starts on the date of shipment of the hardware to the Original Purchaser.

During the warranty period, the Company agrees to repair or replace, at its sole option, without charge to Original Purchaser, any defective component. To obtain service, the Original Purchaser must return the item to the Company properly packaged for shipping. All defective products must be returned to the Company within thirty (30) days of failure. Products must be returned with a description of the failure and Return Merchandise Authorization (RMA) number supplied by the Company. To receive a RMA number and a return shipping address on where to deliver the hardware, call 610-429-1821. The shipping, and insurance charges incurred in shipping to the Company will be paid by Original Purchaser, and all risk for the hardware shall remain with the Original Purchaser until such time as Company takes receipt of the hardware. Upon receipt, the Company will promptly repair or replace the defective unit, and then return said unit to Original Purchaser, shipping prepaid. The Company may use reconditioned or like-new parts or units, at its sole option, when repairing any hardware. Repaired products shall carry the same amount of outstanding warranty as from original purchase. Any claim under the warranty must include dated proof of purchase or invoice. In any event, the Company's liability for defective hardware is limited to repairing or replacing the hardware.

This warranty is contingent upon proper use of the hardware by Original Purchaser and does not cover: if damage is due to Acts of God (including fire, flood, earthquake, storm, hurricane or other natural disaster), accident, unusual physical, electrical, or electromechanical stress, modifications, neglect, misuse, operation with media not approved by the Company, tampering with or altering of the hardware, riot, war, invasion, act of foreign enemies, hostilities (regardless of whether war is declared), civil war, rebellion, revolution, insurrection, military or usurped power or confiscation, terrorist activities, nationalization, government sanction, blockage, embargo, labor dispute, strike, lockout or interruption or failure of electricity, air conditioning, or humidity control, internet, network, or telephone service

The warranties given herein, together with any implied warranties covering the hardware, including any warranties of merchantability or fitness for a particular purpose, are limited in duration to one year from the date of shipment to the Original Purchaser. Jurisdictions vary with regard to the enforceability of warranty limitations, and you should check the laws of your local jurisdiction to find out whether the above limitation applies to you.

The Company shall not be liable to you for loss of data, loss of profits, lost savings, special, incidental, consequential, indirect, or other similar damages arising from breach of warranty, breach of contract, negligence, or other legal action even if the Company or its agent has been advised of the possibility of such damages, or for any claim brought against your by another party. Jurisdictions vary with regard to the enforceability of provisions excluding or limiting liability for incidental or consequential damages. You should check the laws of your local jurisdiction to find out whether the above exclusion applies to you.



This warranty allocates risks of product failure between Original Purchaser and the Company. The Company's hardware pricing reflects this allocation of risk and the limitations of liability contained in this warranty. The warranty set forth above is in lieu of all other express warranties, whether oral or written. The agents, employees, distributors, and dealers of the Company are not authorized to make modification to this warranty, or additional warranties binding on the Company. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by the Company and should not be relied upon.

This warranty gives you specific legal rights. You may also have other rights which vary from one jurisdiction to another.