

# 22-inch LCD Display Unit

## **User Manual**

M6MGEM2131HK02

Thank you for purchasing our product. If there is any question or request, please do not hesitate to contact us. This manual may contain several technically incorrect places or printing errors, and the content is subject to change without notice. The updates will be added into the new version of this manual. We will readily improve or update the products or described in the manual.

## **Regulatory Information**



2002/96/EC (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For

more information see: www.recyclethis.info.



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific

battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info.

## Chapter 1. Introduction

### 1.1 Key Features

- Support 1920×1080 FHD display;
- User-friendly operation menu;
- Three image modes to adapt different environment;
- 1 channel HDMI 1.3 input interface;
- Support software spread-spectrum technology to reduce EMI radiation;
- Standby Power Consumption is lower than 0.4W.
- Viewing Angle: Horizontal 170°, Vertical 160°.

## 1.2 Power Supply Connection

Insert the 3-pin power device into well-grounded socket and turn the rocker switch on.




Figure 1.1 Power Input

- Power input specification from 100VAC to 240VAC or provide automatic switching between high line and low line input ranges.
- Turn off the main power switch of the display unit, and pull the plug from the power outlet if the display unit will not be used for a long time.
- Never connect the device to a DC power.

## **Chapter 2. Device Interfaces**




Figure 2.1 Rear Panel of Device

Interfaces	Description
POWER IN	Power Input
HDMI IN	HDMI Digital Signal Input
VGA IN	VGA Analog Signal Input

## Chapter 3. Panel Keys

Keys on lower right corner of the display unit panel are shown in the Figure 3.1 Keys on the Display Unit.




Figure 3.1 Keys on the Display Unit

The functions of the keys on lower right corner of the display unit vary according to different situations.

## **Chapter 4. Basic Operation**

### 4.1 Input Source Selection

Turn on the display unit when the power supply is on and input source is confirmed.

Press ◀ key of the remote controller to enter the menu as shown on the right. 22 inch LCD display unit includes 2 input sources as HDMI and VGA signal. Press direction keys to select the input source and press MENU to accomplish the input source selection.



Figure 4.1 Input Source

### 4.2 Input Brightness Adjustment

Turn on the display unit when the power supply is on and input source is confirmed.

Press ► key of the remote controller to enter the menu as shown on the right.press ◀ or ► to adjust the value of Brightness. press MENU to accomplish the Brightness adjustment.



Figure 4.2 Brightness

## 4.3 Auto Adjust

Turn on the display unit when the power supply is on and input source is confirmed.

Press **AUTO** key of the remote controller to enter the menu as shown on the right(In VGA Signal).



Figure 4.3 Input Source

#### 4.4 Main Menu

## 4.4.1 Image Settings

#### Purpose:

You can adjust the picture parameters by switching image modes and adjust the values of contrast, brightness, color temperature auto adjust, color adjust.

#### Steps:

- 1. Press Menu key to enter the main menu interface as shown below.
- 2. Press MENU key to enter the setting you want.
- 3. Press ◀ or ▶ to adjust the value. It applies for adjusting contrast, brightness, color temp and other parameters.



- Contrast, Brightness: Press ◀ or ▶ to set the contrast, the range varies from 0-100.
- Gray indicates that under current mode or current input source condition it is not adjustable; Yellow indicates that it is adjustable.

**4.**Press **AUTO** key to return to the main menu after accomplishing the adjustment.




Figure 4.4.1 Image Settings

## 4.4.2 Image Adjustment

#### Purpose:

When the input source is selected VGA, you can adjust the VGA parameters. It is for adjusting VGA H position, V Position, clock and phase.

#### Steps:

- 1. Press Menu key to enter the main menu interface.
- 2. Press ✓ key to enter the VGA parameter setting interface. (You can select Auto Adjust and press ✓ or ► to adjust the VGA parameters automatically or adjust it manually)
- 3. Select **H Position** and press ◀ or ▶ to adjust the **H Position**
- **4.** Select **V Position** and press **◄** or **▶** to adjust the **V position**.
- 5. Select Clock and press ◀ or ▶ to adjust the clock.
- 6. Select Phase and press ✓ or ► to adjust the phase.



The range of the adjustment varies between 0-100.

7. Press Menu key to return to the main menu after accomplishing the adjustment.




Figure 4.4.2 Image Adjustment

## 4.4.3 OSD Setting

### Purpose:

You can set the language, blending and OSD duration of the menu.

#### Steps:

- 1. Press MENU key to enter the main menu interface.
- Press ✓ key twice and press MENU key to enter the 【Language】 interface, press ✓ or ► to switch
  the language you want.
- 3. Select OSD H.Pos/OSD V.Pos to adjust the position of OSD with ◀ or ▶.
- 4. Select OSD Timer to adjust the OSD duration with ◀ or ▶: 5Sec~60Sec.
- 5. Select **Transparency** to adjust the OSD transparency value with ◀ or ▶.
- **6.** Press **AUTO** key to return to the main menu after accomplishing the adjustment.




Figure 4.4.3 OSD Setting

## 4.4.4 Other Settings

#### Purpose:

You can set Mode, Audio Volume, Signal Source, Aspect Ratio, DCR.

#### Steps:

- 1. Press MENU key to enter the main menu interface.
- 3. Press  $\triangleleft$  or  $\triangleright$  to adjust the Audio Volume from  $0\sim100$  (Optional).
- **4.** Press **◄** or **▶** to change the **Signal Source** between **VGA** and **HDMI**.
- 5. Press or ► to switch the **Aspect Ratio** between 16:9/AUTO/4:3.
- 6. Press or ▶ to switch the DCR On/Off.
- 7. Press Menu key to return to the main menu after accomplishing the adjustment.




Figure 4.4.4 Other Settings

## 4.4.5 Reset Setting

#### Purpose:

You can reset settings to the factory defaults.

#### Steps:

1.Press MENU key to enter the main menu interface.



Figure 4.4.5 Reset Setting

Appendix: Specifications

Device Model	HDLED21.5			
Display Type	TFT-LED Backlight			
Screen Size	21.5"			
Dot Pitch	0.248×0.248 mm			
Max Resolution	1920×1080			
Best Operation Resolution	1920×1080@60Hz			
Brightness	250cd/m <sup>2</sup>			
Contrast	1000:1			
Response Time	5ms			
Color	16.7M			
Viewable Area	477×268mm			
Viewing Angle	Horizontal 170°, Vertical 160°			
	VGA Input Port	1		
Interfaces	HDMI Input Port	1		
	AC Input Port	1		
Power Supply	AC 100-240V; 50/60Hz			
Consumption	≤30W			
Standby Power Consumption	≤0.4W			
Operation Temperature	0°C~40°C (32°F~104°F)			
Operation Humidity	10%~85%			
Storage Temperature:	-20°C~55°C (-4°F~131°F)			
Storage Humidity:	5%~95%			
Bezel Material	Plastic			
Bezel Color	Black			
Wall-mounting Dot Site	100×100mm			
Wall-mounting Thread	M4			
Device Dimensions	511×377×170mm			
Package Dimensions	561×426×103mm			
G.W.	4.5Kg			
N.W.	3.3Kg			
	Display Unit	1		
C. 1 1D 1	VGA Cord	1		
Standard Package	User Manual	1		
	Power Cord	1		

## **Structure Figure**

